



Parks and Parkways Pre-Construction Notes

Lily McNee

(o) 504-658-3220

(c) 504-905-1691

ljmcnee@nola.gov

- Provide name and contact information of the licensed arborist.
- A permit for tree removals and pruning must be issued by PPW prior to construction, see Section 3.13 of Special Provisions.
- Schedule a pre-con walk through with the arborist, PPW arborist and staff to review any work planned within the CRZ of any public trees, tree protections, etc.
- Tree protection must be installed and approved by PPW prior to the start of construction. Tree protection should cover the critical root zone. See Tree Protection Detail
- Provide the location of any laydown and storage areas.
- The storage of materials and/or equipment is not permitted on the public right of way or neutral ground.
- Parking is not allowed on the public right of way or neutral ground, contractor is responsible for monitoring and communicating with crew.
- Mechanical excavation/trenching is not permitted under the dripline of a tree.
- Air spading and/or hand digging is permitted under the direction of a licensed arborist.
- Cutting of roots larger than 2 inches in diameter must be done by a licensed arborist.
- Changes in normal traffic patterns may require the pruning of trees outside of the project footprint to obtain proper clearance. Traffic restrictions may need to be enforced.
- Accommodations should be made during road excavations and curb installations within the dripline of a tree.

[Section 01 56 39 Temporary Tree & Plant Protection](#)

[Tree Protection Detail](#)

[Sidewalk Bridging Detail](#)